

Toaster 4-slice code: 261187

Housing made of stainless steel, satined and glossy.
Knobs made of ABS, buttons and pedals made of PP (polypropylene).
Extra wide 4 toasting slots, 2 heating zones (2 slots in each),
2 removable crumb trays.
High-lift lever to remove the toasts effortlessly.

- + Quick toasting of 4 slices of bread at a time
- + 2 separate heating zones with 2 slots each
- + Multifunctional: toast, defrost, reheat
- + Extra wide slots giving flexibility to toast a variety of bread thicknesses
- + 2 removable crumb trays make it easier to clean

Capacity for 4 slices of bread at a time.
7 toasting levels adjusted with knobs – each heating zone can be set up differently.
3 pre-set programmes: toast, defrost, reheat.
3 function buttons for each heating zone: defrost, reheat, eject/cancel.



Code	V	W	LxWxH (W)
261187	240	1500	295x335x(H)180