

Disco raspador code: 280621

Para cortador de vegetais 231807 e 231852.



Código

280621

Code only (W)

280621